

# 3Dconnexion JavaScript Framework

Author:	Nuno Gomes, Markus Bonk
Participant(s):	
Cc:	
Classification:	3Dconnexion Internal Only (Confidential)

## Document history summary:

Version	Author	Date	Status	Comment
1.0	Nuno Gomes	2014-Mar-28	Draft	Preliminary documentation.
1.1	Markus Bonk	2014-Dec-15	Draft	Added description of new methods and updated the existing example code.
1.2	Markus Bonk	2015-Apr-14	Draft	Added putViewExtents description.
1.3	Markus Bonk	2015-Apr-20	Draft	Added console messages and pointer position.
1.4	Markus Bonk	2015-May-05	Draft	Added hit-testing and construction plane descriptions.
1.5	Markus Bonk	2015-May-29	Draft	Added the coordinate system and front view descriptions.
1.6	Markus Bonk	2015-Jun-09	Draft	Included the name of the properties being accessed by the getter and setter methods. Added missing property descriptions.
1.7	Markus Bonk	2015-Sep-14	Draft	Added rotatable property to view.
1.8	Markus Bonk	2016-Dec-08	Draft	Added commands and images.
1.9	Markus Bonk	2017-Jan-24	Draft	Added note about "Default" ActionSet. Corrected the ActionSet and Category constructors.
1.10	Markus Bonk	2017-Oct-19	Draft	Documented transaction property.
1.11	Markus Bonk	2018-Jan-01	Draft	Documented changes to matrix order and mutator naming.
1.12	Markus Bonk	2018-Nov-05	Draft	Documented frame timing properties.
1.13	Markus Bonk	2019-Feb-04	Draft	Fix incorrect coordinate system example.
1.14	Nuno Gomes	2020-Jul-08	Draft	Removed jQuery dependency

<b>1. INTRODUCTION.....</b>	<b>4</b>
1.1 PURPOSE.....	4
1.2 TARGET AUDIENCE.....	4
1.3 DOCUMENT HISTORY.....	4
1.4 REFERENCES.....	5
<b>2. OVERVIEW.....</b>	<b>6</b>
2.1 3DCONNEXION'S INPUT DEVICES .....	6
2.2 3DCONNEXIONJS AND NAVIGATION LIBRARY .....	6
<b>3. USAGE.....</b>	<b>6</b>
3.1 3DCONNEXIONJS FRAMEWORK DEPENDENCIES .....	6
3.2 COORDINATE SYSTEM .....	7
3.3 CONSOLE MESSAGES.....	7
3.4 THE _3DCONNEXION CLASS .....	7
3.4.1 <i>Constructor</i> .....	7
3.4.2 <i>Methods</i> .....	7
3.4.2.1 connect() .....	7
3.4.2.2 create3dmouse() .....	7
3.4.2.3 delete3dmouse() .....	8
3.5 THE _3DCONNEXION.ACTIONTREE CLASS.....	9
3.5.1 <i>Constructor</i> .....	9
3.5.2 <i>Methods</i> .....	9
3.5.2.1 push().....	9
3.5.3 <i>Properties</i> .....	9
3.5.3.1 nodes[] .....	9
3.6 THE _3DCONNEXION.ACTIONSET CLASS.....	10
3.6.1 <i>Constructor</i> .....	10
3.6.2 <i>Methods</i> .....	10
3.6.2.1 push().....	10
3.6.3 <i>Properties</i> .....	10
3.6.3.1 id .....	10
3.6.3.2 label .....	10
3.6.3.3 type .....	10
3.6.3.4 nodes[] .....	10
3.7 THE _3DCONNEXION.CATEGORY CLASS .....	11
3.7.1 <i>Constructor</i> .....	11
3.7.2 <i>Methods</i> .....	11
3.7.2.1 push().....	11
3.7.3 <i>Properties</i> .....	11
3.7.3.1 id .....	11
3.7.3.2 label .....	11
3.7.3.3 type .....	11
3.7.3.4 nodes[] .....	11
3.8 THE _3DCONNEXION.ACTION CLASS.....	12
3.8.1 <i>Constructor</i> .....	12
3.8.2 <i>Methods</i> .....	12
3.8.3 <i>Properties</i> .....	12
3.8.3.1 id .....	12
3.8.3.2 label .....	12
3.8.3.3 description.....	12
3.8.3.4 type .....	12
3.9 THE _3DCONNEXION.IMAGECACHE CLASS.....	13
3.9.1 <i>Constructor</i> .....	13
3.9.2 <i>Methods</i> .....	13
3.9.2.1 push().....	13
3.9.3 <i>Events</i> .....	13
3.9.3.1 onload().....	13
3.9.4 <i>Properties</i> .....	13
3.9.4.1 images[] .....	13
3.9.4.2 outstanding_requests.....	13
3.10 THE _3DCONNEXION.IMAGEITEM CLASS .....	14

3.10.1	Constructor .....	14
3.10.2	Methods .....	14
3.10.3	Properties .....	14
3.10.3.1	id .....	14
3.10.3.2	type .....	14
3.10.3.3	index .....	14
3.10.3.4	buffer .....	14
3.10.3.5	data .....	14
3.10.3.6	status .....	14
3.10.4	Events .....	14
3.10.4.1	onload() .....	14
3.10.5	Functions .....	14
3.10.5.1	fromURL() .....	14
3.10.5.2	fromImage() .....	15
3.11	CLIENT INTERFACE .....	16
3.11.1	Event onConnect() .....	16
3.11.2	Event onDisconnect() .....	16
3.11.3	Event on3dmouseCreated() .....	16
3.11.4	Property 'motion' .....	17
3.11.5	Property 'coordinateSystem' .....	18
3.11.6	Property 'view.constructionPlane' .....	18
3.11.7	Property 'view.fov' .....	19
3.11.8	Property 'view.perspective' .....	19
3.11.9	Property 'view.extents' .....	20
3.11.10	Property 'view.frustum' .....	20
3.11.11	Property 'view.affine' .....	21
3.11.12	Property 'view.rotatable' .....	22
3.11.13	Property 'views.front' .....	22
3.11.14	Property 'model.extents' .....	23
3.11.15	Property 'pivot.position' .....	23
3.11.16	Property 'pivot.visible' .....	23
3.11.17	Property 'pointer.position' .....	24
3.11.18	Frame Properties .....	25
3.11.18.1	Property 'transaction' .....	25
3.11.18.2	Property 'frame.timingSource' .....	25
3.11.18.3	Property 'frame.time' .....	25
3.11.19	Hit-testing Properties .....	26
3.11.19.1	Property 'hit.lookfrom' .....	26
3.11.19.2	Property 'hit.direction' .....	26
3.11.19.3	Property 'hit.aperture' .....	26
3.11.19.4	Property 'hit.selectionOnly' .....	27
3.11.19.5	Property 'hit.lookat' .....	27
3.11.20	Selection Properties .....	28
3.11.20.1	Property 'selection.empty' .....	28
3.11.20.2	Property 'selection.extents' .....	28
3.11.21	Command Properties .....	28
3.11.21.1	Property 'commands.activeCommand' .....	28
3.11.21.2	Property 'commands.tree' .....	29
3.11.21.3	Property 'commands.activeSet' .....	29
3.11.21.4	Property 'images' .....	29

# 1. Introduction

## 1.1 Purpose

This document includes preliminary information on the 3DconnexionJS Framework API. The development of 3DconnexionJS is “work-in-progress”.

## 1.2 Target Audience

The target audience of this document is all 3Dconnexion employees involved in the development of 3DconnexionJS.

## 1.3 Document History

### Version 1.0

- First document version. Includes preliminary information on the 3DconnexionJS framework API. The status of 3DconnexionJS as of document version 1.0 is “work-in-progress / experimental”.

### Version 1.1

- Updated the example code for the update in the samples to glmatrix v2.2. Added description of the methods used by the navlib to support the views commands. The documentation reflects the methods implemented in the webglapp.html sample. Includes preliminary information on the 3DconnexionJS framework API. The status of 3DconnexionJS as of document version 1.1 is “work-in-progress / experimental”.

### Version 1.2

- Added putViewExtents description.

### Version 1.3

- Added console message flags description. Added description of the mouse pointer position.

### Version 1.4

- Added section on hit-testing. Added an example for the construction plane.

### Version 1.5

- Clarified that the methods implemented in the client interface are getter and setter methods for properties. Included the property names. Added selection and pivot properties.

### Version 1.8

- Added on3dmouseCreated description
- Added classes used for command and image export

### Version 1.9

- Added note on “Default’ action set identifier
- Corrected ActionSet and Category constructors
- Corrected create3dmouse example

### Version 1.10

- Added ‘transaction’ property documentation

### Version 1.11

- Documented changes to the matrix order
- Changed the naming to match 3DconnexionJS v0.5 mutators

### Version 1.12

- Documented Frame properties.

Version 1.13

- Fix incorrect coordinate system example.

Version 1.14

- Removed dependency on jQuery.

## 1.4 References

- [1] 3Dconnexion, “3DxWare SDK 3.0 for Windows”; v. 3.0.2, revision 9261; 3Dconnexion Documentation; 11-Sep-2013.
- [2] Tavendo1; Web Application Messaging Protocol (WAMP) version 1; <http://wamp.ws/spec/wamp1/>; Tavendo GmbH; 2014.
- [3] Tavendo2; AutobahnJS; <http://autobahn.ws/js/>. Tavendo GmbH; 2014.

## 2. Overview

The 3DconnexionJS Framework is 3Dconnexion's Application Programming Interface (API) for Javascript applications currently under active development. The information included in this document is subject to change and the documented API is likely to be modified without backward compatibility.

### 2.1 3Dconnexion's input devices

For a detailed explanation on the operation of 3Dconnexion's input device see reference [1]. Note that 3DconnexionJS does not require any additional 3Dconnexion Software Development Kit (SDK) packages.

### 2.2 3DconnexionJS and Navigation Library

Departing from a conventional Software Development Kit for an input device (see [1]), the 3DconnexionJS API uses 3Dconnexion's Navigation Library. The Navigation Library is a module that implements regular navigation modes used with a 3D mouse (object, camera, target-camera, "helicopter") freeing the JS program developers from having to re-implement the control features expected by 3D mouse users.

The 3DconnexionJS API provides a wrapper to the Navigation Library. The Navigation Library will be the base of 3Dconnexion's SDKs for multiple platforms.

## 3. Usage

The 3DconnexionJS framework is implemented in file `3dconnexion.js` and uses version 1 of the WebSocket Application Messaging Protocol (WAMP, see [2]) to transport 3D mouse data into the JavaScript context of a web application. The messaging data is formatted in JavaScript Object Notation (JSON).

The WebSocket connection occurs over the system's loopback adapter with the framework only accepting secure socket connections. Web applications can be delivered by HTTP or HTTPS.

A web application includes `3dconnexion.js` in a `<script>` statement:

```
<script type="text/javascript" src="3dconnexion.js"></script>
```

A "minified" file with a concatenation of `autobahn.js` and `3dconnexion.js` is also available:

```
<script type="text/javascript" src="3dconnexion.min.js"></script>
```

### 3.1 3DconnexionJS Framework Dependencies

In addition to 3Dconnexion's driver and Navigation Library software, the 3DconnexionJS Framework depends on:

- **AutobahnJS**  
AutobahnJS is an open-source implementation of WAMP and copyright of Toledo GmbH. See [2] for additional information.  

```
<script type="text/javascript" src="autobahn.js"></script>
```

  
The script `autobahn.js` is concatenated with `3dconnexion.js` in the "minified" `3dconnexion.min.js` script.

## 3.2 Coordinate System

Internally, the 3DconnexionJS Framework uses a right-handed coordinate system with the Y-axis up and the camera looking down its negative Z-Axis. The Framework will query the client for the client's coordinate system and orientation of the front view when a connection is established (see the client interface properties, later) so that the positions, etc., can be passed to the 3DconnexionJS Framework in the client's coordinate system.

## 3.3 Console Messages

Two flags control the output of console messages during runtime. `_3DCONNEXION_DEBUG` controls the output of the 3DconnexionJS Framework messages and `AUTOBAHN_DEBUG` controls the output of the websocket protocol layer messages. To enable output of one or the other the corresponding flag needs to be defined as true before the 3DconnexionJS Framework is included.

## 3.4 The `_3Dconnexion` Class

Web applications create a `_3Dconnexion` object to use the 3DconnexionJS framework.

### 3.4.1 Constructor

```
_3Dconnexion(object);
```

Arguments:

`object`

Required. This is the client object which supplies the callbacks the `_3Dconnexion` instance uses to pass data back to the client. The methods that the client object is required to define are described below.

### 3.4.2 Methods

#### 3.4.2.1 `connect()`

Establishes a connection to the 3Dconnexion Navigation Server using WAMP as a WebSocket sub-protocol. On a successful connection the client object's `onConnect()` method is invoked. If the client object used to construct the `_3Dconnexion` object has defined an `onDisconnect()` method, this will be called on a disconnect (see the description of the Client methods below).

```
connect()
```

Arguments:

None.

Example:

```
this.init3DMouse = function () {
    var self = this;
    self._3Dconnexion = new _3Dconnexion(self);
    if (!self._3Dconnexion.connect()) {
        console.log("Cannot connect to 3Dconnexion NL-Server");
    }
};
```

#### 3.4.2.2 `create3dmouse()`

Creates a connection to a 3D mouse and a navigation controller for the view. On a successful creation the clients `on3dmouseCreated()` method is invoked.

```
create3dmouse (window, appname, option)
```

**Arguments:**

`window`

Required. This is the window/view instance, typically the canvas used to draw the scene. The `_3Dconnexion` object adds `onfocus` and `onblur` call-backs to the instance to be able to determine keyboard and 3D mouse focus.

`appname`

Required. The `appname` argument is used to identify the application for the 3D mouse property panels and displayed to the user.

`options`

Optional. The `option` argument is used to specify configuration options to the navigation library. The default value is `_3Dconnexion.nlOptions.none`. The only other supported value is `_3Dconnexion.nlOptions.rowMajorOrder` which is used to specify that the matrices are in row major order.

**Example:**

```
this.onConnect = function () {  
  var self = this;  
  var name = 'WebThreeJS Sample';  
  var canvas = document.getElementById('container');  
  self._3Dconnexion.create3dmouse(canvas, name);  
};
```

**Remarks:**

The default matrix representation uses column major order. Should row major order be required then the property `_3Dconnexion.columnMajorOrder` must be set to false before invoking `create3dmouse()`.

### **3.4.2.3 delete3dmouse()**

Deletes the 3D mouse controller.

`delete3dmouse()`

**Arguments:**

None.



## 3.5 The `_3Dconnexion.ActionTree` Class

Container class used to build a tree of commands to be exposed to the 3Dconnexion Properties Buttons panel

### 3.5.1 Constructor

```
_3Dconnexion.ActionTree();
```

Arguments:  
None.

### 3.5.2 Methods

#### 3.5.2.1 `push()`

The `push()` method adds a new item to the end of the array of child nodes, and returns the node.

```
push(node)
```

Arguments:  
`node`.

Required. The `node` must be a `_3Dconnexion.ActionSet` instance.

Example:

```
var actionTree = new _3Dconnexion.ActionTree();
var buttonBank = actionTree.push(
    new _3Dconnexion.ActionSet('ACTION_SET_ID', 'Custom action set'));
```

### 3.5.3 Properties

#### 3.5.3.1 `nodes[]`

Array of child nodes.

## 3.6 The `_3Dconnexion.ActionSet` Class

Class that describes a set of commands. An action set can also be considered to be a button bank, a menubar, or a set of toolbars.

### 3.6.1 Constructor

```
_3Dconnexion.ActionSet(actionSetId, label)
```

Arguments:

`actionSetId`

Required. The `actionSetId` is an application defined unique string identifier for the application command set. This is the value which is updated to the `commands.activeSet` property for the 3Dconnexion UI to select the correct command context.

`label`

Required. This is displayed to the user in the 3Dconnexion UI to identify the action set.

Note: An action set with `actionSetId === 'Default'` will not have its label displayed to the user. 'Default' is the recommended `actionSetId` in applications that only require a single action set.

### 3.6.2 Methods

#### 3.6.2.1 `push()`

The `push()` method adds a new item to the end of the array of child nodes, and returns the node.

```
push(node)
```

Arguments:

`node`.

Required. The `node` can be a `_3Dconnexion.Category` or `_3Dconnexion.Action` instance.

Example:

```
var actionTree = new _3Dconnexion.ActionTree();
var buttonBank = actionTree.push(
  new _3Dconnexion.ActionSet('ACTION_SET_ID', 'Custom action set')
);
buttonBank.push(
  new _3Dconnexion.Action('ID_OPEN', 'Open', 'Open file')
);
```

### 3.6.3 Properties

#### 3.6.3.1 `id`

Application defined unique string identifier.

#### 3.6.3.2 `label`

User readable label.

#### 3.6.3.3 `type`

Node type = `SI_ACTIONSET_NODE`

#### 3.6.3.4 `nodes[]`

Array of child nodes.

## 3.7 The `_3Dconnexion.Category` Class

Class that allows commands to be grouped by category so that the user can find commands easily.

### 3.7.1 Constructor

```
_3Dconnexion.Category(categoryId, label)
```

Arguments:

`categoryId`

Required. The `categoryId` is an application defined unique string identifier for the category.

`label`

Required. This is used in the 3Dconnexion UI to identify the category.

### 3.7.2 Methods

#### 3.7.2.1 `push()`

The `push()` method adds a new item to the end of the array of child nodes, and returns the node.

```
push(node)
```

Arguments:

`node`.

Required. The `node` can be a `_3Dconnexion.Category` or `_3Dconnexion.Action` instance.

Example:

```
var actionTree = new _3Dconnexion.ActionTree();
var buttonBank = actionTree.push(
  new _3Dconnexion.ActionSet('ACTION_SET_ID', 'Custom action set')
);
var fileNode = buttonBank.push(
  new _3Dconnexion.Category('CAT_ID_FILE', 'File')
);
```

### 3.7.3 Properties

#### 3.7.3.1 `id`

Application defined unique string identifier.

#### 3.7.3.2 `label`

User readable label.

#### 3.7.3.3 `type`

Node type = `SI_CATEGORY_NODE`

#### 3.7.3.4 `nodes[]`

Array of child nodes.

## 3.8 The `_3Dconnexion.Action` Class

Class that describes an application command

### 3.8.1 Constructor

```
_3Dconnexion.Action(commandId, label, description)
```

Arguments:

`commandId`

Required. The `commandId` is an application defined unique string identifier for the application command. This is the value which is set to the `commands.activeCommand` property when the user presses the button which has the command assigned.

`label`

Required. This is used in the 3Dconnexion UI to identify the command.

`description`

Optional. Text that allows the user to understand what the command does.

### 3.8.2 Methods

None

### 3.8.3 Properties

#### 3.8.3.1 `id`

Application defined unique string identifier.

#### 3.8.3.2 `label`

User readable label.

#### 3.8.3.3 `description`

User readable text describing the action.

#### 3.8.3.4 `type`

Node type = `SI_ACTION_NODE`

## 3.9 The `_3Dconnexion.ImageCache` Class

Container class for the command images.

### 3.9.1 Constructor

`_3Dconnexion.ImageCache()`

Arguments:

None.

### 3.9.2 Methods

#### 3.9.2.1 `push()`

The `push()` method adds a new item to the end of the array of images.

`push(item)`

Arguments:

`item`.

Required. The `item` must be an instance of `_3Dconnexion.ImageItem`.

Example:

```
var images = new _3Dconnexion.ImageCache();
images.push(
  _3Dconnexion.ImageItem.fromURL('images/open.png', 'ID_OPEN')
);
```

### 3.9.3 Events

#### 3.9.3.1 `onload()`

The `onload()` event is called when all outstanding http get requests for the images have been satisfied.

`onload()`

Arguments:

None.

Example:

```
var cache = new _3Dconnexion.ImageCache();
cache.onload = function () {
  self._3Dconnexion.update3dcontroller({ 'images': cache.images });
};
```

### 3.9.4 Properties

#### 3.9.4.1 `images[]`

Array of `_3Dconnexion.ImageItem` items

#### 3.9.4.2 `outstanding_requests`

number of image load requests which are outstanding

## 3.10 The `_3Dconnexion.ImageItem` Class

Container class for a command image.

### 3.10.1 Constructor

```
_3Dconnexion.ImageItem()
```

Arguments:

None.

### 3.10.2 Methods

None.

### 3.10.3 Properties

#### 3.10.3.1 `id`

The `id` is an application defined string identifier. To associate an image with a `_3Dconnexion.Action` item, the ids need to be identical.

#### 3.10.3.2 `type`

The `ImageItem` instance type. Currently only `_3Dconnexion.SiImageType_t.e_image` and `_3Dconnexion.SiImageType_t.e_none` are supported.

#### 3.10.3.3 `index`

Defines the image index when using a collection of sub-images contained in a wider image (image list). The default is 0.

#### 3.10.3.4 `buffer`

Used internally to store the images data.

#### 3.10.3.5 `data`

Accessor to the internal buffer

#### 3.10.3.6 `status`

Status of the XMLHttpRequest to load the image

### 3.10.4 Events

#### 3.10.4.1 `onload()`

The `onload()` event is called when an outstanding XMLHttpRequest get request for the image has completed.

```
onload()
```

### 3.10.5 Functions

#### 3.10.5.1 `fromURL()`

The `fromURL` function creates a `_3Dconnexion.ImageItem` object from an URL.

```
_3Dconnexion.ImageItem.fromURL(url, id)
```

Arguments:

`url`

`url` Required. The `url` of the image

`id` Required. The `id` of the command the image is to be associated with.

Example:

```
var images = new _3Dconnexion.ImageCache();
images.push(
  _3Dconnexion.ImageItem.fromURL('images/open.png', 'ID_OPEN')
);
```

### 3.10.5.2 fromImage()

The `fromImage` function creates a `_3Dconnexion.ImageItem` object from an `arrayBuffer`.

```
_3Dconnexion.ImageItem.fromImage(arrayBuffer, id)
```

Arguments:

`arrayBuffer`

Required. The `arrayBuffer` containing the image

`id`

Required. The `id` of the command the image is to be associated with.

### 3.11 Client interface

The client interface consists of methods implemented by the web application (the client of the `_3Dconnexion` object) and used by the framework to access client properties or signal events. The Navigation Server is a program running in the user host context and implements the WebSocket server and the wrapper code to access the Navigation Library and 3D mouse driver. The 3Dconnexion Navigation Library implements the scene navigation models by querying the client for properties of the scene or the view/camera, applying transformations derived from the input 3D mouse data to the acquired values and then setting the updated properties in the client. The 3Dconnexion Navigation Library accessing the client properties through getter and setter methods implemented by the client.

#### 3.11.1 Event `onConnect()`

Mandatory method which is called when a successful connection has been made to the 3Dconnexion Navigation Server allowing the client to finish initialization. Typically the client will call the `_3Dconnexion` object's `create3dmouse()` method.

`onConnect()`

Implementation:  
Mandatory.

Arguments:  
None.

Example:

```
this.onConnect = function () {
    var self = this;
    var namePos = window.location.pathname.lastIndexOf("/");
    var name = window.location.pathname.substring(namePos + 1);
    var canvas = document.getElementById('container');
    self._3Dconnexion.create3dmouse(canvas, name);
};
```

#### 3.11.2 Event `onDisconnect()`

Optional method which is called after an unsuccessful connection attempt to the 3Dconnexion Navigation Server

`onDisconnect(reason)`

Implementation:  
Required for any post disconnect processing.

Arguments:  
`reason`  
An error number.

Example:

```
this.onDisconnect= function (reason) {
    console.log("3Dconnexion NL-Server disconnected " + reason);
};
```

#### 3.11.3 Event `on3dmouseCreated()`

Optional method which is called when the 3DMouse controller instance is successfully created. Typically the client will initialize the application/web page specific button data here.



`On3dmouseCreated()`

Implementation:

Optional.

Arguments:

None.

Example:

```
this.on3dmouseCreated = function () {
    var self = this;
    var actionTree = new _3Dconnexion.ActionTree();
    var actionImages = new _3Dconnexion.ImageCache();
    actionImages.onload = function () {
        self._3Dconnexion.update3dcontroller({
            'images': actionImages.images
        });
    };
    var buttonBank = actionTree.push(
        new _3Dconnexion.ActionSet('ACTION_SET_ID', 'Custom action set')
    );
    getApplicationCommands(buttonBank, actionImages);

    self._3Dconnexion.update3dcontroller({
        'commands': {
            'activeSet': 'ACTION_SET_ID', 'tree': actionTree
        }
    });
};
```

### 3.11.4 Property ‘motion’

**Event `onStartMotion()`**

Method called by the Navigation Server once when it is about to start moving the view and updating the view matrix. The client can use this event to initialize the animation loop. When the Navigation Library has finished moving the view `onStopMotion()` will be invoked (see below). `onStartMotion()` and `onStopMotion()` occur in pairs.

`onStartMotion()`

Implementation:

Required to start the animation frame loop.

Associated Navlib property: “motion”

Arguments:

None.

Example:

```
this.onStartMotion = function () {
    var self = this;
    if (!self.animating) {
        self.animating = true;
        window.requestAnimationFrame(self.render.bind(self));
    }
};
```

**Event `onStopMotion()`**

Method called by the Navigation Server after it has invoked `onStartMotion()` when it will no longer update the view. `onStartMotion()` and `onStopMotion()` occur in pairs.

`onStopMotion()`

Implementation:

Required to stop the animation frame loop

Associated Navlib property: "motion"

Arguments:

None.

Example:

```
this.onStopMotion = function () {  
    this.animating = false;  
};
```

### 3.11.5 Property 'coordinateSystem'

**Getter Method** `getCoordinateSystem()`

Method called by the Navigation Library when a connection is established to determine the pose of the application's world coordinate system described in the Navigation Library's coordinate system (x to the right, y-up, and z into the screen). In most cases the matrix will be the inverse of the front view's matrix. The matrix is returned as a 1 x 16 array.

`getCoordinateSystem()`

Implementation:

Required to convert between the client coordinate system to the navigation library coordinate system

Arguments:

None.

Example:

```
this.getCoordinateSystem = function () {  
    // The following is for X to the right, Z-up, Y into the screen  
    return [1,0,0,0, 0,0,-1,0, 0,1,0,0, 0,0,0,1];  
};
```

### 3.11.6 Property 'view.constructionPlane'

**Getter Method** `getConstructionPlane()`

The method returns a 1x4 java array containing the general form of the construction plane. This property is used by the Navigation Library to distinguish views used for construction in an orthographic projection: typically the top, right left etc. views. The library assumes that when the camera's look-at axis is parallel to the plane normal the view should not be rotated.

`getConstructionPlane()`

Implementation:

Required for the orthographic 2d view algorithms.

Arguments:

None.

Example:

```
this.getConstructionPlane = function () {  
    var self = this;  
  
    // a point on the construction plane  
    var origin = new THREE.Vector3(0., 0., 0.);
```

```

origin.applyMatrix4(self.grid.matrixWorld);

// In this sample the up-axis is the y-axis
var yAxis = new THREE.Vector3();
self.grid.matrixWorld.extractBasis(new THREE.Vector3()
    , yAxis
    , new THREE.Vector3());
var d0 = yAxis.dot(origin);
// return the plane equation as an array
return [yAxis.x, yAxis.y, yAxis.z, -d0];
};

```

Note:

If there is no construction plane return null;

### 3.11.7 Property 'view.fov'

#### Getter Method `getFov()`

Method called by the Navigation Library when it needs to know the field-of-view (fov) of the camera/view. The method returns the vertical fov in radians.

```
getFov()
```

Implementation:

Required for zooming in perspective projections.

Arguments:

None.

Example:

```

this.getFov = function () {
    return this.gl.fov;
};

```

#### Setter Method `setFov()`

Method called by the Navigation Library when it wants to update the fov of the camera/view.

```
setFov(fov)
```

Implementation:

Required for zooming in perspective projections.

Arguments:

`fov`

The fov in radians.

Example:

```

this.setFov = function (fov) {
    this.gl.fov=fov;
};

```

### 3.11.8 Property 'view.perspective'

#### Getter Method `getPerspective()`

The `getPerspective` method returns if the view is a perspective projection.

```
getPerspective()
```

Implementation:

Required to distinguish between orthographic and perspective navigation algorithms.

Arguments:

None.

Example:

```
this.getPerspective= function () {  
    return true;  
};
```

### 3.11.9 Property 'view.extents'

#### Getter Method `getViewExtents()`

The method returns a 1x6 java array containing the min and max extents of the view bounding box. The view extents defines the visible viewing volume of an orthographic projection in view coordinates as min = [left, bottom, -far] and max = [right, top, -near].

```
getViewExtents()
```

Implementation:

Required for orthographic projections.

Arguments:

None.

Example:

```
this.getViewExtents = function () {  
    return [this.view.left, this.view.bottom, -this.view.farVal  
        , this.view.right, this.view.top, -this.view.nearVal];  
};
```

#### Setter Method `setViewExtents()`

The method receives a 1x6 java array containing the min and max extents of the view bounding box. The view extents defines the visible viewing volume of an orthographic projection in view coordinates as min = [left, bottom, far] and max = [right, top, near]. The Navigation Library will call `setViewExtents` when navigating in an orthographic projection in order to zoom the view.

```
setViewExtents(extents)
```

Implementation:

Required for zooming orthographic projections.

Arguments:

`extents`

1x6 array containing the min and max extents of the view.

Example:

```
this.setViewExtents = function (data) {  
    // Only change the size of the view,  
    // ignore the back and front clipping planes  
    this.view.left = data[0];  
    this.view.right = data[3];  
    this.view.bottom = data[1];  
    this.view.top = data[4];  
};
```

### 3.11.10 Property 'view.frustum'

#### Getter Method `getViewFrustum()`

The method returns a 1x 6 java array containing the frustum of the perspective view/camera in camera coordinates. This may be called by the Navigation Library when it needs to calculate the field-of-view of the camera, or during algorithms that need to know if the model is currently visible within the frustum. The Navigation Library will not write to the 'view.frustum' property, instead it will write to the 'view.fov' property and leave the client to change the frustum as required.

`getViewFrustum()`

Implementation:

Required for perspective projections.

Arguments:

None.

Example:

```
this.getViewFrustum = function () {
    var self = this;
    var tan_halffov = Math.tan(self.gl.fov * Math.PI / 360.);
    var bottom = -self.camera.near * tan_halffov;
    var left = bottom * self.camera.aspect;
    if (TRACE_MESSAGES)
        console.log('frustum=[' + left + ', ' + -left + ', ' + bottom + ', '
        + -bottom + ', ' + self.camera.near + ', ' + self.camera.far + ']);
    return [left, -left, bottom, -bottom, self.camera.near, self.camera.far];
};
```

Remarks:

The values in the array are the same as those passed to `glFrustum` in OpenGL.

### 3.11.11 Property 'view.affine'

#### Getter Method `getViewMatrix()`

The method returns a java array containing the view 4x4 column major matrix. This may be called by the Navigation Library when calculating a next frame. The view matrix describes the transform from view coordinates to world coordinates of the view/camera position. Generally `getViewMatrix()` is called by the library at the beginning of motion.

`getViewMatrix()`

Implementation:

Required for navigation.

Arguments:

None.

Example:

```
this.getViewMatrix = function () {
    return Array.prototype.slice.call(this.cameraMatrix);
};
```

Remarks:

OpenGL and WebGL have both implemented matrices as column major.

#### Setter Method `setViewMatrix()`

Method called by the Navigation Library when it has calculated the position of the view for the next frame.

`setViewMatrix(columnMajorMatrix)`

Implementation:  
Required for navigation.

Arguments:  
`columnMajorMatrix`  
The 4x4 view matrix as a column major order array.

Example:

```
this.setViewMatrix = function (data) {  
    this.cameraMatrix = data;  
    this.updateScene();  
};
```

### 3.11.12 Property 'view.rotatable'

#### Getter Method `getViewRotatable()`

The method returns a true or false. This may be called by the Navigation Library when calculating a next frame. The rotatable describes whether the view in an orthographic project can be rotated.

```
getViewRotatable()
```

Implementation:  
Required for 2d navigation.

Arguments:  
None.

Example:

```
this.getViewRotatable = function () {  
    return false;  
};
```

Remarks:  
The Navigation Library will treat non-rotatable views as pure pan-zoom views and also disable the views keys (Right, Left, Top, etc.). To allow the navigation library to rotate the view to an alternative orientation such as Top, define the view as rotatable and a corresponding construction plane.

### 3.11.13 Property 'views.front'

#### Getter Method `getFrontView()`

Method called by the Navigation Library when a connection is established to determine the pose of the front view. When the user presses the 'Front' button on a 3D Mouse this will be the pose the Navigation Library switches to. All other view orientations are calculated from this.

```
getFrontView()
```

Implementation:  
Required for the named views algorithms

Arguments:  
None.

Example:

```
this.getFrontView = function () {  
    // In this sample the front view corresponds to the world pose  
    return [1,0,0,0, 0,1,0,0, 0,0,1,0, 0,0,0,1];  
};
```

### 3.11.14 Property 'model.extents'

#### Getter Method `getModelExtents()`

Method called by the Navigation Library when it needs to know the bounding box of the model. One example of when this will happen is when the library needs to zoom the view to the extents of the model. The extents are returned as an array containing the min and max values of the bounding box in world coordinates.

```
getModelExtents()
```

Implementation:

Required for the pivot and zoom algorithms.

Arguments:

None.

Example:

```
this.getModelExtents = function () {  
    var min = vec3.create();  
    vec3.transformMat4(min, this.model.extents.min, this.modelMatrix);  
    var max = vec3.create();  
    vec3.transformMat4(max, this.model.extents.max, this.modelMatrix);  
    return [min[0], min[1], min[2], max[0], max[1], max[2]];  
};
```

### 3.11.15 Property 'pivot.position'

#### Getter Method `getPivotPosition()`

Method called by the Navigation Library when it wants to know the position of the 2D mouse pivot or of a pivot manually set by the user. The position is returned as a 1x3 array in world coordinates.

```
getPivotPosition()
```

Implementation:

Required for rotating about the pivot position

Arguments:

None.

#### Setter Method `setPivotPosition()`

Method called by the Navigation Library to set the position of the pivot. The pivot position is in world coordinates.

```
setPivotPosition(position)
```

Implementation:

Required for changing the pivot position.

Arguments:

`position`

position of the 3D mouse pivot in world coordinates

### 3.11.16 Property 'pivot.visible'

#### Setter Method `setPivotVisible()`

Method called by the Navigation Library when it wants to set the visibility of the pivot used for the 3D mouse. This will be dependent on the user setting for the pivot visibility in the

3Dconnexion 3D mouse settings panel and whether the Navigation Library is actively navigating the scene.

```
setPivotVisible(visible)
```

Implementation:

Required for changing the 3D mouse pivot visibility.

Arguments:

`visible`  
true if the pivot should be visible, otherwise false

### 3.11.17 Property 'pointer.position'

**Getter Method** `getPointerPosition()`

Method called by the Navigation Library when it requires the world position of the mouse pointer on the projection/near plane.

```
getPointerPosition()
```

Implementation:

Required for the quick zoom algorithms.

Arguments:

None

Example:

```
// getPointerPosition is called when the navlib needs to know where
// the mouse pointer is on the projection/near plane
this.getPointerPosition = function () {
  var self = this;

  var canvas = document.getElementById('container');
  var rect = canvas.getBoundingClientRect();

  // position of the mouse in the canvas (windows [0,0] is at the top-
  // left of the screen, opengl[0,0] is at the bottom-left)
  // the position is tracked relative to the window so we need to
  // subtract the relative position of the canvas
  // Setting z=0 puts the mouse on the near plane.
  var pos_opengl = new THREE.Vector3(window.mouseX - rect.left,
    self.gl.viewportHeight - (window.mouseY - rect.top), 0.0);
  if (TRACE_MESSAGES)
    console.log('Mouse Position =[' + pos_opengl.x + ', ' +
      pos_opengl.y + ', ' + pos_opengl.z + ']');

  // three.js has screen coordinates that are (-1,-1) bottom left and
  // (1,1) top right.
  var pos = new THREE.Vector3(pos_opengl.x / self.gl.viewportWidth *
    2.0 - 1.0, pos_opengl.y / self.gl.viewportHeight * 2.0 - 1.0
    , pos_opengl.z * 2.0 - 1.);

  // make sure the matrices are up to date
  self.camera.updateProjectionMatrix();
  self.camera.updateMatrixWorld();

  pos.unproject(self.camera);
  return pos.toArray();
};
```



### 3.11.18 Frame Properties

#### 3.11.18.1 Property 'transaction'

##### Setter Method `setTransaction()`

Method called by the Navigation Library at the beginning and end of a frame change. At the beginning of a frame change the Navigation Library will set the 'transaction' property to a value >0. When the Navigation Library has completed the changes to the frame, the value is reset to 0. Clients that do not use an animation loop and need to actively refresh the view can trigger the update when the value is set to 0.

```
setTransaction(transaction)
```

Implementation:

Required to refresh the view

Arguments:

`transaction`

The current transaction

Example:

```
this.setTransaction = function (transaction) {  
  if (transaction === 0) {  
    // request a redraw  
    this.updateScene();  
  }  
};
```

#### 3.11.18.2 Property 'frame.timingSource'

By setting the 'frame.timingSource' property to 1, the client application informs the Navigation Library that the client has an animation loop and will be the source of the frame timing. (See the 'frame.time' property below).

Example:

```
this.on3dmouseCreated = () => {  
  const self = this;  
  // set ourselves as the timing source for the animation frames  
  self.spaceMouse.update3dcontroller({  
    'frame': { 'timingSource': 1 }  
  });  
};
```

#### 3.11.18.3 Property 'frame.time'

When the 'frame.timingSource' property is set to 1, the client initiates a frame transaction by informing the Navigation Library of the new frame time. The frame time type is double and is the time stamp of the frame.

Example:

```
// the callback that results in the scene being rendered  
this.render = function (time) {  
  const self = this;  
  if (self.animating) {  
    // Initiate a new frame transaction by updating the controller  
    // with the frame time.  
    self.spaceMouse.update3dcontroller({  
      'frame': { 'time': time }  
    });  
    // Request an animation frame for the next incoming transaction  
    // data.  
    window.requestAnimationFrame(self.render.bind(self));  
  }  
};
```

```

    }

    // Render the current scene.
    self.drawScene();
};

```

### 3.11.19 Hit-testing Properties

The Navigation Library includes navigation algorithms that are dependent on the size of and the distance to the model being viewed. This can be at the view centre or at the position of the mouse cursor. When these algorithms are activated, the Navigation Library may require the client to perform hit-testing. In this case the Navigation Library will set up a ray and query the nearest hit.

#### 3.11.19.1 Property 'hit.lookfrom'

##### Setter Method `setLookFrom()`

Method called by the Navigation Library that defines the origin of the ray used in hit-testing.

```
setLookFrom(origin)
```

Implementation:

Required for the auto pivot algorithms.

Arguments:

`origin`

The position of the origin of the ray in world coordinates.

Example:

```

this.setLookFrom = function (data) {
    this.ray.origin = data;
};

```

#### 3.11.19.2 Property 'hit.direction'

##### Setter Method `setLookDirection()`

Method called by the Navigation Library that defines the direction of the ray used in hit-testing.

```
setLookDirection(direction)
```

Implementation:

Required for the auto pivot algorithms.

Arguments:

`direction`

The direction of the ray in world coordinates.

Example:

```

this.setLookDirection = function (data) {
    this.ray.direction = data;
};

```

#### 3.11.19.3 Property 'hit.aperture'

##### Setter Method `setLookAperture()`

Method called by the Navigation Library that defines the diameter of the ray used in hit-testing.

```
setLookAperture(aperture)
```

Implementation:

Required for the auto pivot algorithms.

Arguments:

`aperture`

The diameter of the ray in world coordinates.

Example:

```
this.setLookAperture = function (data) {  
    this.ray.aperture = data;  
};
```

#### 3.11.19.4 Property 'hit.selectionOnly'

**Setter Method** `setSelectionOnly()`

Method called by the Navigation Library that defines whether hit-testing should include all the objects or be limited to the current selection set.

`setSelectionOnly(selection)`

Implementation:

Required for the auto pivot algorithms.

Arguments:

`selection`

If hit-testing should only be performed on the current selection set then this value is true, otherwise false.

Example:

```
this.setSelectionOnly = function (data) {  
    this.hittest.selectionOnly = data;  
};
```

#### 3.11.19.5 Property 'hit.lookat'

**Getter Method** `getLookAt()`

Method called by the Navigation Library when it requires the world position of the nearest intersection of the "look" ray with the scene or selection set.

`getLookAt()`

Implementation:

Required for the auto pivot algorithms.

Arguments:

None.

Example:

```
this.getLookAt = function () {  
    var self = this;  
  
    // Create a raycaster  
    var raycaster = new THREE.Raycaster(self.ray.origin,  
        self.ray.direction, self.gl.frustumNear,  
        self.gl.frustumFar);  
    raycaster.precision = self.ray.aperture / 2.;  
    raycaster.linePrecision = self.ray.aperture / 2.;  
  
    // do the hit-testing  
    var intersects = raycaster.intersectObjects(self.scene.children);  
    if (intersects.length > 0) {  
        var lookAt = new THREE.Vector3();
```

```

        lookAt.copy(self.ray.direction);
        lookAt.multiplyScalar(intersects[0].distance);
        lookAt.add(self.ray.origin);
        if (TRACE_MESSAGES)
            console.log('lookAt=[' + lookAt.x + ', ' + lookAt.y + ', ' +
                lookAt.z + ']');
        return lookAt.toArray();
    }
    // If nothing was hit return nothing
    return null;
};

```

### 3.11.20 Selection Properties

Dependent on the user's action and settings, the Navigation Library pivot and zoom algorithms will be modified if a subset of the model in the scene is selected. The Navigation Library will query if the current selection set is empty and if not then request the extents of the selection set.

#### 3.11.20.1 Property 'selection.empty'

**Getter Method** `getSelectionEmpty()`

Method called by the Navigation Library to determine if the current selection set is empty. The method returns true if the selection is empty.

```
getSelectionEmpty()
```

Implementation:

Required for the auto pivot algorithms and zoom algorithms

Arguments:

None.

#### 3.11.20.2 Property 'selection.extents'

**Getter Method** `getSelectionExtents()`

Method called by the Navigation Library when it needs to know the bounding box of the selection set. One example of when this will happen is when the library needs to zoom the view to the extents of the selection. The extents are returned as an array containing the min and max values of the bounding box in world coordinates.

```
getSelectionExtents()
```

Implementation:

Required for the auto pivot algorithms and zoom algorithms

Arguments:

None.

### 3.11.21 Command Properties

Application commands are exposed to the 3Dconnexion property panel using the commands properties. These can be assigned to buttons on the 3D Mouse by the user to create custom 3D Mouse configurations for when the web page is in focus.

#### 3.11.21.1 Property 'commands.activeCommand'

**Setter Method** `setActiveCommand()`

Method called by the Navigation Library when the user presses a 3D Mouse button that has been assigned an application command.

```
setActiveCommand(commandId)
```

Implementation:

Required for application commands

Arguments:

`commandId`

This is an application define string used to identify the command. See the `_3Dconnexion.ActionTree` class for further details.

Example:

```
this.setActiveCommand = function (commandId) {  
  if (commandId)  
    console.log("Id of command to execute= " + commandId);  
};
```

#### 3.11.21.2 Property 'commands.tree'

The client exposes commands to the 3Dconnexion property panel by updating the 3Dmouse controller's 'commands.tree' property with a `_3Dconnexion.ActionTree` instance. See the `_3Dconnexion.ActionTree` class for further details.

Example:

```
_3Dconnexion.update3dcontroller({  
  'commands': {  
    'tree': actionTree  
  }  
});
```

#### 3.11.21.3 Property 'commands.activeSet'

The commands exposed to the 3Dconnexion property panel may contain more than one action set/button bank. This allows context sensitive button configurations. The client application uses this property to set which action set is active. If the property is not set, the 3Dconnexion driver will use the action set which is defined as default in the profile for the application.

Example:

```
_3Dconnexion.update3dcontroller({  
  'commands': {  
    'activeSet': 'ACTION_SET_ID'  
  }  
});
```

#### 3.11.21.4 Property 'images'

Images can be associated with commands. These are exposed to the 3Dconnexion UI elements by updating the 'images' property with an array of `_3Dconnexion.ImageItem` instances. See the `_3Dconnexion.ImageCache` class for details.

Example:

```
3Dconnexion.update3dcontroller({  
  'images': actionImages.images  
});
```